


Steering systems and axle suspensions




1000HS(II)/1000HS(ck)

Tritronic (2016)

User manual

Release (05/2020)



EG -DECLARATION OF COMPLIANCE

Directive 2006/42/EG, Annex II-B



Manufacturer: TRIDEC, Transport Industry Development Centre B.V.
Address : Ekkersrijt 6030,
5692 GA Son,
the Netherlands
hereby declares that the product:

Model : 1001HS(II)/1001HS(ck)

Product number : 1000

Commercial name : 1001HS(II)/1001HS(ck)
to which this declaration refers, is in compliance with the provisions
stipulated in the following guideline:

- 70/311/EEG/R79
- 94/20/EEG/R55
- R10

Quality control by:

**SGS-International Certification Services GmbH,
Rödingsmarkt 16,
D-20459 Hamburg
Germany**

Conducted at Son 29/04/2020, the Netherlands

TRIDEC


Frans Lipman

Director




A handwritten signature in blue ink, appearing to read 'Frans Lipman', is placed over the printed name and title.





HS(II) with linear attachment



HS(cp) with linear attachment



Tritronic 2016


Table of contents

Foreword	1
1 Description	3
1.1 Product variants	3
1.2 Operation	5
1.2.1 HS..steering system	5
1.2.2 Operating	6
1.2.3 Components	7
1.2.4 Switch box	8
1.2.5 Computer	10
1.2.6 Selector switch	12
2 Remote control	13
2.1 Touchscreen	14
2.2 Scope of delivery	15
2.3 Replacing batteries	16
2.4 Screen brightness	19
2.5 Configuring language	20
2.6 Configuring key sounds	21
2.7 Function keys	22
2.8 Connection with computer	23
2.9 Stop button	24
2.10 Icons	25
3 Operating the Tritronic system	28
3.1 Using button for programme selection	28
3.2 Operating the remote control	29
3.2.1 Main menu	30
3.2.1.1 Activating menus by means of push buttons	30
3.2.1.2 Activating menus using the touchscreen	31
From "Transit (Trans)" to "Operational (Oper)"	31
3.2.2 "Low pressure" light	33
3.2.3 Standby mode	35
3.2.4 Steering left and right	36

3.2.5 Alignment	37
3.2.6 Drive height (with drive height monitoring (Default))	40
3.2.6.1 Abort drive height control	42
4 Additional functions	43
4.1 Activating additional function	43
Signal lights	44
Signal lights	44
5 Information and error messages and warnings	45
5.1 Information messages	45
5.2 Error messages	48
6 Emergency operation	51
6.1 Valves overview	51
6.2 Manual operation with power source	52
6.3 Manual operation without power source	54
6.3.1 Steering wheels	54
6.3.2 Height control	55
7 Putting into service	56
7.1 Vehicle registration and delivery	56
7.2 Coupling and uncoupling	57
7.3 Use of a steered semi-trailer	59
8 Safety & environment	61
8.1 Safety while operating	61
8.1.1 Danger zones for other road users	62
8.2 Environment	63
9 General information	64
9.1 Cleaning	64
9.2 System information	66
9.2.1 Wireless (Bluetooth)	66
9.2.2 Software versions	67
9.2.3 Serial and order number	68
9.2.4 Steering sensors	69
9.2.5 Suspension sensors	70

9.3 Pictograms	72
9.4 Type indication	73
10 Maintenance periods	76
10.1 Daily maintenance	78
10.1.1 Lubricant	79

Foreword

 This guide is intended for drivers and/or other HS..steering system users contains the necessary TRIDEC information regarding the use of the HS..steering system. This user manual must always be stored in the vehicle.

A separate maintenance, settings and repair manual for service technicians is available on the website: www.tridec.com.

Separate installation instructions for the system are supplied upon delivery of the HS..steering system.

Effective use:

The HS..steering system is not designed to be used independently. It has been designed to be mounted as an external steering system to a trailer/semi-trailer. Any modifications whatsoever could compromise the safety of the system. Both the TRIDEC product guarantee and the homologation shall be rendered invalid if these products are modified without written consent from TRIDEC. All guarantee claims against TRIDEC or suppliers of the HS..steering system shall be declared invalid if the HS..steering system is not installed according to the instructions supplied by TRIDEC.

Prior to putting the system into service, compliance with the applicable national road traffic regulations must be established for the trailer on which the system is installed. The system may only be used in accordance with the manual for the truck and any other trailer manuals.

The diagrams in this manual are only included as examples and are not intended for any other purposes. Images shown may vary slightly from the system supplied.



All safety information is outlined in chapter 9 (see "Safety & environment" on page 61). Safety risks are depicted using pictograms in all other chapters.

Contact details:

Tridec Transport Industry Development Centre BV
5692 GA Son, the Netherlands
Tel: +31(0) 499 491050
www.tridec.com

info@tridec.com



Validity and copyright:

No part of this document may be reproduced and/or published by print, photocopy, microfilm or any other manner whatsoever without written consent from Tridec. The diagrams and specifications have been diligently compiled and we cannot be held responsible for any inaccuracies. Tridec retains the right to modify the technical aspect of parts without prior notification. Please contact Tridec for more information on this subject.

© Copyright Tridec, Son, the Netherlands

Date of issue: 29 April 2020 Original version: 1.0

1 Description

The following paragraphs contain information about the components that make up the HS..steering system and how the system works.

1.1 Product variants

The HSseries from the TRIDEC product range can be supplied as the following version(s), that is, the:

- HS (II) steering system
- HS(ck) steering system

A steering system consists of:

- one fifth wheel unit
- one attachment
- one or more axle assembly frames (abbreviated to 'AAF')
- one or more steering rods




Figure 1-1

The HS..steering system is suitable for installation on:

- A chassis with longitudinal members (II)
- A chassis with a central main beam (ck)

Both variants can be supplied with:

- Manual pump
- Compact system
- Tritronic system

Aligned with the chassis width of the semi-trailer, several width variants of the fifth wheel unit (1) and the axle assembly frame (5) can be supplied. The fifth wheel unit is fixed to the chassis by means of brackets. The axle assembly frame is fixed to the chassis with the installed slewing ring by means of bolts also supplied by TRIDEC. The fifth wheel unit has a linear or progressive attachment. A linear steering system has a different steering behaviour than a progressive steering system. Roughly speaking, the semi-trailer with a progressive steering system steers up to a towing angle (the angle between the tractor unit and semi-trailer) of 35° sharper than a semi-trailer with a linear steering system (see 'Danger zones for other road users' on page 1).

From a construction perspective, the chassis must be strengthened by means of cross-members (3) where the axle assembly frame is located. The attachment (2) and cylinders (4) on the semi-trailer are connected to each other by means of hydraulic lines.

The chassis with longitudinal members has cylinders that are installed on a separate frame (4) behind the last axle assembly frame. The rear axle assembly frame is connected to the cylinders while the other axle assembly frames are connected to each other by means of steering rods. The chassis with a central main beam has cylinders that are installed on the central main beam. The cylinders are connected to one axle assembly frame. The axle assembly frames are connected to each other by means of steering rods.


The hydraulic circuit can only be expanded with additional functions in relation to the compact and Tritronic systems. Examples are extra ramps and height adjustment. In relation to the three versions, there is an option to turn the wheels in the straight position in emergency situations by using the manual pump function.

1.2 Operation

Below, the operational principle of the different HS.. systems is described. These steering systems minimise the path followed by tractor unit semi-trailer combinations when taking bends. The stability when driving in a straight line again is realised by giving wheels a caster structurally.

1.2.1 HS..steering system

When the coupled tractor unit takes a bend to the right, the steering box section (2) is pushed backwards by the slewing ring (1) on the fifth wheel unit. The sliding joint (3) of the transfer lever is pushed away and therefore the piston rods of the cylinders are put in motion. Depending on the method used to connect the cylinders to the semi-trailer, the piston rods on the semi-trailer are put in motion. In this case, the piston rod (6) extends out of the cylinder while the piston rod of the other cylinder slides into the cylinder. The Rear axle assembly frame (5) is connected to the cylinders and rotates clockwise. The axle assembly frames are connected to each other using the steering rods (4) and therefore all axle assembly frames rotate clockwise. Every axle assembly frame turns at a different angle.



160040_39

Figure 1-2

1.2.2 Operating

A trailer with a hydraulic steering system or other hydraulic functions can be operated externally using the Tritronic system.

This makes it possible to adjust the steering angle of the wheels on the steered axes while manoeuvring a truck with a trailer. That makes manoeuvring much easier. Once manoeuvring is complete, the wheels can be automatically returned to the driving position.




Figure 1-3

The angles of the trailer wheels are constructively fixed and depend on the angle of the truck relative to the centre line of the trailer.

In order to make external steering possible, the Tritronic system programme must run the so-called "Configuration procedure". The Tritronic system detects the angle made between the truck and the centre line of the trailer and the associated wheel angles of the trailer during this procedure. These values are stored in the steering programme.


If necessary, it is possible to configure practical vertical positions for the trailer.

This could include minimum and maximum drive-heights. Once configured, the chassis can be steered to the set positions by pressing a shortcut on the remote control.

A number of other hydraulic and electrical functions can be configured and directed in this manner.

1.2.3 Components

 The Tritronic system consists of the following main components:




617403_053

Figure 1-4

- | | |
|--------------------|---------------|
| 1. Remote control | 6. Computer |
| 2. Selector switch | 7. Container |
| 3. Angle sensor | 8. Keycord |
| 4. Cables | 9. Sync cable |
| 5. Switch box | |

1.2.4 Switch box





The diagram below shows items that are relevant to the user.






1701_081


Figure 1-5

1. Model sticker: The part and serial number are found on the sticker.
2. Status LED: "Power" (see table below)
3. Climate membrane: Prevents internal formation of condensation by allowing for the exchange of air.
4. Status LED: "Status" (see table below)
5. Guarantee seal: This seal may not be removed or reused.
6. Button: Pump override. The hydraulic pump can be turned on using this button.
7. Front of switch box.
8. Back of switch box.

		The guarantee is rendered invalid if the seal is broken or removed.
		Please note!: The climate membrane does NOT contain a fuse.

System mode		Colour "Power" LED	Pattern	Colour Status LED	Pattern	Description
Normal		Green	Continuous	Green/Red	Green/Red (1x/sec)	Connection with computer active
Mal-function		Green	Continuous	Red	Red Continuous	Programme error
Reversed		Red	Continuous			Power cables connected incorrectly

Cleaning



617403_090

Figure 1-6

1.2.5 Computer

The diagram below shows items that are relevant to the user.




Figure 1-7

- 1. Model sticker: The part and serial number are found on the seal.
- 2. Status LED: "Power" (see table below)
- 3. Climate membrane: Prevents internal formation of condensation by allowing for the exchange of air.
- 4. Status LED: "Status" (see table below)
- 5. Guarantee seal: This seal may not be removed or reused.

		The guarantee is rendered invalid if the seal is broken or removed.
		Set the selector switch to "Transit mode" when driving on public roads.
		Please note!: The climate membrane does NOT contain a fuse.




System mode		Colour "Power" LED	Pattern	Colour Status LED	Pattern	Description
Normal		Green	Continuous	Green/Red	Green/Red (1x/sec.)	Computer active
Malfunction		Green	Continuous	Red	Red Continuous	Programme error
Reversed		Red	Continuous			Power cables connected incorrectly
Connections/Service		Green	Continuous	Green	Green/Red (1x/sec.)	The switch box and the computer are communicating
		Green	High frequency blinking	Green	Continuous	No communication with switch box

Table-1 Computer LEDs

1.2.6 Selector switch

The selector switch has two positions: "Transit" and "Operational". These can be activated by using the selector switch or the remote control. If the Tritronic system is not being used on public roads, then the "Transit" option **must** be activated.

When in "Transit" mode, the following programme functions are active or possible:

- the predetermined automatic functions (e.g. automatic ride-height).
- functions that should be available as per client request.



If using the remote control in "Transit" mode, a message will appear on the screen if a function is not available.

There is an antenna in the selector switch for the "blue tooth" connection.

When in "Operational" mode, the user has the following options:

- the Tritronic system programme can be configured.
- all steering functions can be used.

The diagram below shows items that are relevant to the user.



1701_067_1

Figure 1-8

1. Climate membrane:
This membrane prevents internal formation of condensation by allowing for the exchange of air. Do not cover this membrane (no fuse).
2. "Low pressure" light:
The pressure in the hydraulic system is too low.
3. Switch:
This switch can deactivate the desired programme, "Transit" or "Operational".
4. LED:
The LED indicator shows which utilisation area of the programme is active.

2 Remote control



For safety reasons, moving parts must remain in the field of view of the operator when using the remote control.



NEVER operate the remote control while driving on a public road.

The remote control is a part of the Tritronic system. The Tritronic system can be operated with the remote control by means of a wireless connection ("Bluetooth") or via the synchronisation cable.



If configured, the remote control will be put into "Standby mode" when not used for 2 minutes. (see "Standby mode" on page 35).

The tractor unit's ignition switch should be turned to the accessories position when using the remote control.





Figure 2-1

2.1 Touchscreen

As well as button controls, the remote control has a touchscreen. There are thus two ways of activating functions and menu options.



 The illustrations above show, in this case, that the menu "Controls" can be activated in 2 ways.




The illustrations in this user manual show operation via the buttons only.

2.2 Scope of delivery

The remote control consists of the following components:

- A synchronisation cable for linking the remote control to the computer.
- A holder. This allows connection between the remote control and a 12 V or 24 V source.
- A lanyard ("keycord").



2.3 Replacing batteries




The following message will appear at the bottom of the screen when the batteries have reached the end of their lifespan.





Figure 2-2

Batteries may only be replaced with rechargeable NiMH (Nickel Metal Hydride) AAA size batteries with a recommended capacity of 800 mAh.

Batteries should be removed if the remote control will not be used for an extended period of time. Do not place completely discharged batteries into the remote control. The system does not have sufficient capacity to charge them.





Charging the batteries

The batteries in your remote control can be charged in the following ways:

- By using the charging cable. It has a plug that can be connected to the 12 V or the 24 V socket in the cabin.
- By using a synchronisation cable that can be connected to Tritronic system computer.



The batteries will not be overcharged if the remote control is left connected to a power source for an extended period of time.

The following information will appear on the screen if the remote control has been connected to a power source (Min. 9 V).



617403_093



Figure 2-3


If the remote control has been switched off and is connected to a power source, the following message will appear on the screen.



617403_222

2.4 Screen brightness

1. Follow the steps below to set the screen brightness.
2. Press  to return to the previous menu. Press  repeatedly to return to the main menu.



2.5 Configuring language

The remote control's standard start-up language is order specific. Other languages can be manually configured.

Procedure:

1. Follow the steps below to change the language settings (turn the remote control off).



Figure 2-4



2. Press the following key combinations to activate the desired language.



Figure 2-5

 Press one of the buttons 1, 2, 3 or 4. While holding the button press OK.

2.6 Configuring key sounds

1. Execute the following steps in order to turn the key sound on or off.
2. Press  to return to the previous screen.
(Press  repeatedly to return to the main menu.)



2.7 Function keys

In addition to a screen, the remote control also has a number of keys. Use these keys to activate functions or to select menus.



Figure 2-6









No.	Item	Description
1	Touch screen	See overview of icons on the screen.
2		Navigate to the page in the menu.
3		Activate selected functions.
4		Selection the "Config Menu". Activating automatic functions (STD). May deviate.
5		Return to the previous page.
6		Order specific menus are linked to the numeric keys. Example: 1 is the "Steering" menu, 2 is the "Suspension" menu, etc.
7		Turning the remote control on and off. Confirmation of message.
8		Menu selection "System info" or activation of automatic functions.
9		All active processes are being aborted.


Table-2 Function keys

2.8 Connection with computer

The remote control can be connected to the computer in two ways:


1. Wireless via "blue tooth".
2. Via the synchronisation cable.

The icon  will be displayed if there is a "bluetooth" connection between the remote control and the computer.

If the remote control is connected with a cable, then this icon  will be displayed on the screen.




If you have no signal, stand near the selector switch with the remote control to test the "bluetooth" connection. The range is normally 100 m direct line of sight.



617403_089

Figure 2-7

2.9 Stop button

A stop function is included in the remote control program. As soon as the relevant button  is pressed, all the active processes are halted.




The  button is not an "EMERGENCY STOP".



617403_218



The button  is not intended to interrupt actions during normal use. For this, use the appropriate keys or key combinations.



2.10 Icons









Specific information will be displayed on the screen in the form of icons. The meaning of each of these icons is described in the table.



Figure 2-8

Icons and texts

Position	Icon	Description
1A	ALIGN	Hydraulic aligning is active
1A	AUTO	Adjusting to drive height
1A	EXTRA	Adjusting to alternative height
1A	LEVEL	Busy leveling
1A	LEARN	A teaching in process is active
1A	LIFT	The lifting axle raises to it's highest position.
1A	LOW	The chassis lowers down to it's lowest set vertical position.
1A	SLOPE	Adjusting to it's set slope angle. Pre-set angle maintained
1A	RELIEF	The system pressure is being relieved.
1A	TIMER	One off the timers is active.
1B	ABS	Steering and automatic alignment is permitted.
1C		Blue tooth connection active
1C		The remote is connected to a power supply.

Position	Icon	Description
1D		Progress of an ongoing process
1E		Starting the HS..steering system with default settings
1E		"Restore mode": The settings that were in use when the Tritronic system programme was shut down will be reactivated when this function is activated.
1F	TRANS	"Transit mode": A limited number of functions can be activated when the vehicle is moving.
1F	OPER	"Operational mode": All functions can be activated if the vehicle is stationary.
1F		"Switch box" not in operation. No communication.
1G	AUTO	Automatic drive height control is active.
1G	EXTRA	Alternative height control is active
1G	LEVEL	Depending on the position of the levellingssensor the chassis or the trailer body is level
1G	LOAD	Automatic height control between the lowest vertical position and the drive height is active.
1G	LOW	Driving with the lowest vertical position that was taught in.
1G	SLOPE	Slope driving active. Set angle will be preserved.
1G		No controll programm active
1H		Battery full
1H		Battery half-full
1H		Battery empty
1H		Battery is being charged
1K		Left side alignment is OK.






Position	Icon	Description
1K		Left side alignment is not ok
1L		Right side alignment is OK.
1L		Right side alignment is not OK.
1M		Scroll to next page in menu when available.

Table-3 Icons

3 Operating the Tritronic system

In order to operate the Tritronic system, the truck's ignition switch must be turned to the accessory position. If this is the case, the "low pressure" light on the selector switch will blink twice.



617403_075

Figure 3-1

After configuration, the Tritronic system is ready for use. The menu functions can now be used. It is also possible to store personalised settings (ride-height, position of the chassis relative to the axles). The chassis can be moved to the pre-set position using the shortcut. Operating the Tritronic system is described in the following paragraphs.

3.1 Using button for programme selection

Procedure:

1. Turn the truck's ignitions switch (1) to the "I" position (accessory position). The programme last used, "Transit" or "Operational", will be reactivated.
2. Press the button (2) 1x in order to activate the "Transit" or "Operational" programme. The blue LED next to the activated programme will light up.



Figure 3-2

The "Transit" programme **MUST** be activated when driving on public roads.

3.2 Operating the remote control

The Tritronic system is an external steering system that can be used to operate the hydraulic and electrical functions of a trailer. Steering is done by means of a remote control.

For example, if the trailer has been equipped with a hydraulic steering system for the wheels, the wheels can then be steered using the remote control. Automatic functions can be activated by using shortcuts. For example, by activating the function (see "Alignment" on page 37) using the shortcut, the wheels of the trailer / semi-trailer will be turned to the angle that corresponds with the angle of the truck to the trailer / semi-trailer.


 	Steering the trailer using the Tritronic system relies on the EBS signal.
	Steering and/or alignment is NOT permitted if the brakes or the handbrake is engaged.
	Steering and/or alignment is NOT permitted if the trailer is stationary and laden or decoupled.

Key behaviour

The keys or key combinations can be programmed with either a touch or a timer function.

Keys or key combinations with a touch function need to be kept pressed for at least 2 seconds in order to activate the hydraulic or electrical function. After releasing the key, movement will continue until the position has been achieved.

Key or key combinations with a timer function need to be kept pressed for at least 2 seconds in order to activate the hydraulic or electrical function. After releasing the key, movement will continue for the amount of time programmed. A message will be displayed.

	The user should experiment with the keys or key combinations in order to become more familiar with their behaviour.
---	---

3.2.1 Main menu



The function menus displayed on the screen are order specific. The following diagrams are examples only.

3.2.1.1 Activating menus by means of push buttons

Once the main menu has more than 5 items, the numerical keys have a double function. The illustration below shows a possible main menu with the associated functions.




617403_065

Figure 3-3

1. Press 1x briefly on the numerical key 1, 2, 3, 4 or 5, and the appropriate submenu is displayed on the screen.

Example:




617403_066

2. Press briefly on the key  to bring up the other items in the main menu.

Carry out the procedure below to bring up the other submenus:


1. Press 2x on 1, 2, 3, 4 or 5 to bring up the appropriate submenus of the items 6, 7, 8, 9 or 10.

Example: Menu item 6 is in this case "Ramps". Press 2x on ❶. The submenu of "controls" comes up first. After that, the submenu for "Ramps" comes up.



3.2.1.2 Activating menus using the touchscreen

The submenus of the items on the main menu can also be activated by tapping the item required on the screen.



From "Transit (Trans)" to "Operational (Oper)"


It is only possible to activate the functions if the selector switch (mode switch) is in the "Operational" mode.

Carry out the procedure below if the text "Trans" is displayed at the bottom of the screen.



617403_068





Procedure:




The LED next to the program that is activated lights up blue on the selector switch.

3.2.2 "Low pressure" light



The "low pressure" light will blink 2x when the truck's ignition switch is turned to position "I" (accessories position). The light will burn continuously if the oil pressure in the hydraulic system is too low. The light will not burn if there is sufficient oil pressure in the system.


 	<p>Danger!: Do not drive the vehicle if the "low pressure" light is burning continuously. Check the oil levels in the generator. If the "low pressure" light is allowed to burn continuously, other individuals could be put in danger. It could also lead to system damage.</p>
 	<p>Note!: The "low pressure" light must always be visible from the cabin!</p>





1701_068_1

Figure 3-4



1. Execute the following steps to test if the "low pressure" light is working.
2. Press  to return to the previous screen.
3. Press  repeatedly to return to the main menu.






3.2.3 Standby mode

Procedure:

1. Follow the steps below to configure the standby options.
2. Press  to return to the previous screen. Press  repeatedly to return to the main menu.






Active		The screen will turn off after two minutes.
Not active		The screen will remain on.
Ignition key		The screen will turn off after 2 minutes if the ignition switch is turned to "0" or is removed. The screen will remain on if the ignition key is turned to "Acc" or "I".

Table-4 Standby mode

3.2.4 Steering left and right




This function can be activated only in "Operational" mode at speeds lower than 12.5 mph (20 km/u) (see "From "Transit (Trans)" to "Operational (Oper)"" on page 31).



Refer to the document [164001 EN-1](#) to configure steering

Procedure:

1. Follow the steps below to steer the wheels using the remote control.



The Tritronic system can be optionally expanded to include (see "Signal lights" on page 44). These lights are on in different situations. For example, one of the lights is on if the steering angle of the wheels on the trailer is more than 3° greater than the pre-set angle.

3.2.5 Alignment

Here, alignment is understood to mean that the wheels of the trailer / semi-trailer are automatically turned back to the configured angle that corresponds to the angle of the tractor unit in relation to the trailer / semi-trailer.

If one of the windows on the screen lights up red, the semi-trailer / trailer is out of alignment. For example when correcting the steering.



617403_221



This function can be activated only in "Operational" mode at speeds lower than 12.5 mph (20 km/u) (see "From "Transit (Trans)" to "Operational (Oper)"" on page 31).



Refer to the document [164001 EN-1](#) to configure steering


Procedure

1. Follow the steps below to align the trailer with the tractor unit hydraulically using the remote control.



617403_012

617403_036



Drive at a speed lower than 12.5 mph (20 km/h).

(Press **SET** to interrupt the aligning process.)

The screen displays the following information:



Figure 3-5

Once the alignment procedure has been successfully completed, the next message appears on the screen.



617403_041

Figure 3-6

Automatic alignment will stop if the speed increases to a level higher than that programmed into the EBS computer. An error message will be displayed.



617403_042

Figure 3-7

Automatic alignment is possible up to a maximum of 40° between tractor unit and trailer / semi-trailer. An error message will be displayed for angles greater than 40° and automatic alignment will not be possible.

2. Repeat steps 1 to 3 if an error message appears.

3.2.6 Drive height (with drive height monitoring (Default))

Following activation of the "Drive height" function, the chassis of the semi-trailer shifts to the drive height, and the program constantly readjusts to the drive height if there are deviations while moving.



This function can be activated only in "Operational" mode at speeds lower than 12.5 mph (20 km/h) (see "From "Transit (Trans)" to "Operational (Oper)"" on page 1).





Refer to the document [164001 EN-1](#) to configure drive height

Follow the procedure below to activate this function.

Procedure:



Ensure that there are no persons and/or animals in the immediate vicinity of moving parts.



217984_51

Once the drive height has been reached, the message below appears.



617403_086



Messages (Green) disappear of their own accord after a few seconds.
The error messages (Red) do not disappear of their own accord.
Both messages disappear immediately on pressing **OK**.



While this function is active, the text "AUTO" remains displayed on the screen.

If the drive height is not reached within a set time, the message below (see "Drive height not reached" on page 1) is displayed on the screen.




617403_087



Figure 3-8

Press **OK** to return to the menu.

3.2.6.1 Abort drive height control

1. Follow the steps below.



Danger! The procedure can be interrupted by means of the buttons  . However, pressing these buttons may result in the activation of other functions, which may lead to dangerous and unexpected situations and movements of the chassis.

4 Additional functions

Additional operational functions can be added to the Tritronic system programme. The number of optional operational functions is determined by the hydraulic and electrical options which have been fitted to the trailer. The functions are therefore order specific.

Some examples:

- Hydraulically operated ramps
- Hydraulically operated loading flap
- Hydraulic lifting of an axle
- Rotary beacon


4.1 Activating additional function

Procedure:

1. Follow the steps below.



Figure 4-1

2. Press the numerical key (1-5) to activate the appropriate menu.
3. Keep the numerical key 1, 2, 3, 4 or 5 pressed to activate the 6th, 7th, 8th, 9th or 10th menu as required.
4. Press the key or key combination to activate the function required.
5. Where necessary, press  to page through the main menu



Consult the document 162013 EN-1 for further information concerning the additional functions.

Signal lights

Signal lights

The Tritronic system can be optionally expanded to include signal lights. The lights will burn in the following situations.

- When the angle between the truck and the trailer exceeds 40° (see diagram).
- If no steering angles have been configured (see "Steering configuration" on page 1).
- If the steering angle deviates more than 3° from the previously configured value. The trailer is not following the truck in alignment (see "Alignment" on page 37).

These lights are on the left and right of the front bulkhead on the trailer / semi-trailer and mounted in view of the driver.




Figure 4-2



The angle β in the diagram is normally set to 40° . It may sometimes have a lower value. See delivery agreement.

5 Information and error messages and warnings



Important: When using optional functions, error and information messages and warnings may be displayed. In such cases, refer to the semi-trailer manufacturer's operator manual.



Ignoring messages may result in damage to the system!

5.1 Information messages

Status messages

Messages may appear on the screen when the system is in operation. These messages inform the user of the status (see image) of an active function. The screen will light up in green momentarily. The message will disappear automatically after 10 seconds.



617403_062

Figure 5-1

1. Press  to dismiss the message straight away.

No data




Figure 5-2

This message will display after the remote control has started up if the remote control is not synchronised.

Procedure

1. *Follow the steps below.*



1701_087

Figure 5-3

2. *Follow this step to synchronise.*
The message will disappear from the screen after synchronising.







Figure 5-4

3. Check if all functions are working properly in a suitable testing area. Adjust if necessary.



Not conducting this check could lead to dangerous situations!

5.2 Error messages

		Important: When using optional functions, error and information messages may be displayed. In that case, consult the trailer manufacturer manual.
		Ignoring messages could cause damage to the system!

An error message will appear on the remote control as soon as the programme detects a malfunction (see diagram). The screen will light up in red and a short beep will sound.

1. Press  to dismiss the message.



		The screen will continue to light up in red until the error has been resolved. Consult the error code table.
---	---	--



Figure 5-5

Code	Message	Solution
30 000	UNKNOWN	Contact TRIDEC
30 001	Axle sensor steering	Check axle sensor and cable
30 002	Kingpin sensor steering	Check kingpin sensor and cable
30 003	Suspension sensor rear right	Check suspension sensor rear right
30 004	Suspension sensor rear left	Check suspension sensor rear left
30 005	Level sensor	Check level sensor and cable
30 006	Command cylinder blocked	Manual action/ remove blockage

Code	Message	Solution
30 007	Fuse malfunction of internal power supply	Contact TRIDEC
30 008	Fuse malfunction of internal neutral	Contact Tridec
30 009	Incorrect CAN connector switch box	Swap CAN connectors in switch box.
30 010	Automatic alignment taking too long	Repeat alignment. Release the brake. Disengage handbrake.
30 011	Automatic alignment failed	Repeat alignment
30 012	Steering configuration taking too long	Repeat configuration
30 013	Loading ramps not released	Press release button
30 014	Brakes engaged	Release brakes
30 015	Command blocked. Digital 3 displayed	Remove blockage digital input 3
30 016	Command blocked. Digital 4 displayed	Remove blockage digital input 4
30 017	Command blocked. Digital 5 displayed	Remove blockage digital input 5
30 018	No Steering configuration set	Set steering
30 019	Incorrect password Press OK	Enter correct password
30 020	No suspension configuration set	Set suspension
30 021	Kingpin and axle sensors	Check kingpin and axle sensors
30 022	Left and right suspension sensors	Check left and right suspension sensors and cables
30 028	Low pressure	Check system pressure level
30 029	Ride-height not achieved	Try again. Release the brake. Disengage handbrake.
30 030	Self-levelling not achieved	Try again. Release the brake. Disengage handbrake.
30 031	Towing angle too great	Reduce the angle between vehicle and trailer
30 032	Speed too high	Reduce speed / check ABS/EBS signal
30 033	Suspension sensor front right	Check suspension sensor front right and cable
30 034	Suspension sensor front left	Check suspension sensor front left and cable
30 035	Tritronic power supply too low	Check computer power supply min. 12V max. 24V
30 036	Switch box power supply too low	Check switch box power supply
30 037	No communication with switch box	Check the cable between computer and switch box

Code	Message	Solution
30 038	Lowest position not reached	Release the brake and try again.
30 039	Incline drive not achieved	Try again
30 040	Not in operational mode	Switch to operational mode
30 041	System in debug mode	Check if the switch box is connected to the computer. Remove the system from debug mode by restarting. Press OK

Table-5 Error messages

6 Emergency operation

If the remote control is not working, all trailer functions connected to the Tritronic system can still be activated. The manner in which this is done depends on whether there is a power source available or not.

6.1 Valves overview

There is a valve overview within the valve housing. This overview is put together order specific. The figures show an example of such an overview.




Figure 6-1




Figure 6-2

6.2 Manual operation with power source



Please note!: Manual steering of the wheels is **ONLY** permitted when the trailer is coupled. This is done to prevent unwanted movement in the front of the trailer.



Please note!: Manual steering is **NOT** permitted if the brake or hand-brake is engaged.

Steering wheels

1. Follow the steps below to steer the wheels.




Figure 6-3



Please note!: The wheels must be returned to the driving direction after manual operation is complete!

2. Reinstall everything in reverse order. Do not forget the O rings!!!



Danger: Do not drive until all parts have once again been installed!

Procedure:

1. Follow the steps below to set the height of the chassis.



Consult the diagram in the hydraulics cabinet for the function assignments of the 4 buttons!








Figure 6-4



Ensure that no one is in the vicinity of the trailer when operating the height control!

6.3 Manual operation without power source

It is possible to execute the hydraulic functions even if the remote control is not working and there is no power source.

		Please note!: Manual steering of the wheels is ONLY permitted when the trailer is coupled. This is done to prevent unwanted movement in the fifth wheel plate.
		Please note!: Manual steering is not permitted if the brake or hand-brake is engaged.

6.3.1 Steering wheels

Procedure:

1. Follow the steps below to steer the wheels.






Figure 6-5

		Please note!: The wheels must be returned to the driving direction after manual operation is complete!
---	---	--

2. Reinstall everything in reverse order. Do not forget the O rings!!!





Danger: Do not drive until all parts have once again been installed!

6.3.2 Height control

Procedure:

1. Follow the steps below to set the height of the chassis.



1701_057

Figure 6-6



Ensure that no one is in the vicinity of the trailer when operating the height control!




Please consult the trailer manufacturer's manual regarding operating all other hydraulic functions of the trailer.

7 Putting into service

The following paragraphs contain information regarding putting the HS..steering system into service.

7.1 Vehicle registration and delivery

 All associated documentation (vehicle registration certificate, CE declaration, user guide, service manual) for the relevant HS..steering system should be handed to the client upon delivery of a trailer with a HS..steering system.



The vehicle may not be used until compliance with the applicable national road traffic regulations has been established for the trailer on which the HS..steering system is installed.



The national road traffic regulations are specific to each country. Contact the national inspection authority in the relevant country for the necessary information.

Subject	Action
Vehicle Registration Certificate	Submit the vehicle registration certificate to the national inspection authority of the country in which the trailer will be registered. The specifications and approval numbers necessary can be found on the vehicle registration certificate.
Warning sticker	Ensure that the warning sticker has been placed in such a way that it is clearly visible to the driver.
CE declaration of compliance	Store the CE declaration with the vehicle documents in accordance with applicable guidelines.
User guide	Provide the client with the HS..steering system user guide. Instruct the client to keep the user guide with the trailer.
Maintenance and repair manual	Provide the client with the HS..steering system maintenance and repair manual. This manual contains the necessary information needed for the workshop to maintain the system.

Table-6 Client documents

7.2 Coupling and uncoupling




Figure 7-1




Figure 7-2




Figure 7-3



Ensure that both the tractor unit and semi-trailer are on the same horizontal surface when coupling and uncoupling.



NEVER park the semi-trailer with steered wheels.



Do not couple or uncouple when there are people or animals in the immediate vicinity of the semi-trailer and tractor unit.

7.3 Use of a steered semi-trailer

The steering behaviour of an unsteered semi-trailer deviates from the steering behaviour of a steered semi-trailer. The centre of rotation (A) of a steered semi-trailer is closer to the tractor unit. This has an impact on the turning radius (C) and the required space on the road. Manoeuvring through narrow streets is simpler with a steered semi-trailer/trailer.




Figure 7-4

- | | |
|--|---|
| 1. Steering behaviour of an unsteered semi-trailer | 3. B = Required space for the semi-trailer swinging out |
| 2. Steering behaviour of a steered semi-trailer | 4. C = Turning radius of a semi-trailer |
| | 5. D = Required space on the carriageway |

The different phases during driving in a bend are shown using colours. The red dotted line shows the described path of the tractor unit and the semi-trailer. The figure (see Figure 7-4) shows that the unsteered semi-trailer has a larger turning radius and therefore needs more space on the carriageway to take a bend.



When taking a bend, the rear side (B) of a steered semi-trailer swings out further than the rear side of an unsteered semi-trailer.




If you do not have any experience with a steered semi-trailer, TRIDEC recommends gaining experience at a site to practice before you go on a public road with your tractor semi-trailer combination.

8 Safety & environment

The following paragraphs contain information regarding safe use of the HS..steering system. It also describes what should be done when the HS..steering system reaches the end of its lifespan.

8.1 Safety while operating

 Operating a trailer with a HS..steering system installed may involve some possible risks. Consult the relevant regulations (for example: road traffic regulations, company procedures, health and safety regulations) which are applicable to the country where the trailer will be used.



General instructions for operating a trailer with a HS..steering system:


- **NEVER** use or put a trailer with an installed HS..steering system on public roads until compliance with the national road traffic regulations has been established for the entire trailer.
- Read the user guide **BEFORE** coupling and using a trailer with a HS..steering system.
- Execute the daily inspection **BEFORE** coupling and using a trailer with a HS..steering system.
- The truck driver is **ALWAYS** responsible for the use of a trailer.
- **NEVER** drive with a trailer if a signal lamp is lit.
- Only steer the trailer using the HS..steering system if there are **NO** people in the immediate vicinity of the trailer's moving parts.

The nature of possible dangers and restrictions during use are depicted below in the pictograms.



8.1.1 Danger zones for other road users

When a tractor unit with a semi-trailer takes a bend, more space on the carriageway is used. This means that the other road users such as, for example, oncoming vehicles and cyclists will have less space to manoeuvre. The driver of the tractor unit must be fully aware of this and pay extra attention.




8300_062

Figure 8-1

The red areas (see Figure 8-1) indicate where there is a potential danger for other road users when a tractor unit with a steered semi-trailer takes a bend. The red areas demand extra attention during the manoeuvre.

8.2 Environment

 The HS..steering system must be dismantled and disposed of in accordance with local and national regulations once it has reached the end of its lifespan, regardless of the cause. Contact your local or national public services, waste management authority or the supplier you purchased the product from for more information regarding locations where the materials can be collected for recycling.


9 General information

The following paragraphs contain information regarding the delivery, storage and guarantee of the HS..steering system .



Read the following paragraphs when products are delivered!

9.1 Cleaning



1701_095

Figure 9-1




Figure 9-2

160021_49


9.2 System information

You can find information regarding the "bluetooth" connection, programme version and the order number in the "System information menu". It is also possible to view readings of the steering and suspension sensors.

9.2.1 Wireless (Bluetooth)

Procedure:

1. Follow the steps below to request information regarding the "bluetooth" connection.



2. Press to return to the previous screen.
Press repeatedly to return to the main menu.


9.2.2 Software versions

Procedure

1. Follow the steps below to request the software versions for the system components.



This information may be of use with service queries.




2. Press to return to the previous screen.
Press repeatedly to return to the main menu.

9.2.3 Serial and order number

Procedure:

1. Follow the steps below to request the component serial numbers and the order number.



2. Press to return to the previous screen.
(Press repeatedly to return to the main menu.)






This information may be useful for service queries.

9.2.4 Steering sensors

The values in the "Steering sensors" menu display the actual deflection between the truck and the trailer and the deflection of the wheels on the steered axle respectively.

Procedure:

1. Follow the steps below to request the relevant information.
2. Press  to return to the previous screen. Press  repeatedly to return to the main menu.



9.2.5 Suspension sensors


The numbers visible in the "Suspension sensors" menu (height control), are dependant on the functions that the trailer has been fitted with and are therefore order specific. The numbers are indicative and are used to indicate whether the sensors are working.



This information may be useful for service queries.

Procedure:

1. Follow the steps below to request the relevant information.
2. Press to return to the previous screen. Press repeatedly to return to the main menu.



The value 180° indicates that no sensor is present or a sensor is not working properly.



Figure 9-3

The numbers 0,9 (front), -1,3 (rear left) and -0,5 (rear right) indicate that the suspension sensors are working. The number shown next to "∠" ($-90,0^\circ < x, y^\circ < 90,0^\circ$) indicates that the level sensor is working. The number on the up side of the trailer indicates the angle between the trailer and the horizontal plane. The number at the bottom of the chassis indicates the angle between the chassis and the horizontal plane.



Note! The values indicate that the relevant sensors are working. This does not necessarily mean that they are working correctly.

9.3 Pictograms

The following pictograms are used in this user guide:


















Description	Description	Description
 Important message!	 Tip	 Delivery information.
 Danger of becoming trapped!	 Read this information before you start!	 Information regarding use!
 Provisions set by TRIDEC.	 Recycle	 Alignment tool
 Tyre pressure	 Driving direction	 False
 Important restriction!	 Chance of damage to the system!	 Parts
 Lubricate		

Table-7 Pictograms


9.4 Type indication

Products manufactured by TRIDEC (see Figure 9-5), are given an identification sticker.




8300_007

Figure 9-4



160021_40

Figure 9-5



160033_12

Figure 9-6




Figure 9-7

The sticker provides essential information for ordering replacement parts. All product-specific information can be obtained by referencing the serial number on the sticker.

- Type: coding for the product version.
- Serial no.: the order number (required when ordering parts).
- Year: year of construction.



Never remove the sticker affixed by TRIDEC!



The serial number is required for obtaining the correct service information and for ordering parts.

The meaning of the type coding on the sticker is given in the table below (example).

SE 15 10 STD G	Description
S	Steering system
E or T/D/V	Number of axles under the semi-trailer (E=1, T=2, D=3, V=4 or 5)
15/20 or 26.5	Maximum load (tonnes) on the fifth wheel unit (1 tonne = 1000 kg)
10	Number of steered axles (00=0, 10=1, 20=2, etc.)
S/T	Turntable type S=1200 T=1110
TD	Type of steering system
G/K/T	Type of fifth wheel unit (G= bolt connection K= extra-low version)

SE 15 10 STD G	Description
XXXXX-X-XXX	Serial number

Table-8 Type indication

10 Maintenance periods


		
Maintenance when commissioning		
Slewing rings	Lubricate the slewing rings	see the service manual

Table-9 Maintenance


		
Maintenance after 10,000 km or after 2 months at most		
Slewing ring	Lubrication	see the service manual
Kingpin	Retighten bolts and nuts	see the service manual

Table-10 Maintenance


		
Maintenance every 25,000 km or every three months. (Under extreme conditions* every 10,000 km or every 1.5 months.)		
Fifth wheel unit	Lubricate at all grease nipples.	

Table-11 Maintenance

*If used in countries where it rains often and a lot and/or where a lot of salt is gritted in the winter on the roads such as in the UK, Ireland, Denmark, Norway, Sweden and Finland.

*If the vehicle is regularly cleaned using chemicals.


Maintenance after 100,000 km or after 12 months at most

Slewing ring	Measure the axial/radial clearance.	see the service manual
Steering wedge	Free movement and wear	see the service manual
Kingpin	Wear	see the service manual
Ring plate	Deformations	see the service manual

Table-12 Maintenance

10.1 Daily maintenance

The HS..steering system is basically maintenance free. TRIDEC, however, recommends that the visual checks below be performed before any use;







	Check	Action
	 Check for missing or loose bolts and nuts.	Tighten loose bolts or nuts using the correct tightening moment. If required, install new bolts and/or nuts.
	Check the semi-trailer for damage that may have an impact on the driving behaviour.	Contact the service workshop if there is damage.
	 Check that the semi-trailer/trailer follows the tractor unit in a straight line (see Figure 10-1).	Check for damage to the steering system and align the semi-trailer.

Table-13 Maintenance



160021_46

Figure 10-1

10.1.1 Lubricant

Lubricate a HS..steering system using a lubricant that meets the NLGI class 2 specification. If a central lubrication system has been connected, a grease type may be used that meets the NLGI class 0 or NLGI class 2 specification. Verify this using the manual of the central lubrication system.



Only use lubricants that are prescribed by TRIDEC in a HS..steering system.
Other lubricants are **NOT** permitted.




Caution! Replace lubricants of a HS..steering system within the maintenance period set by TRIDEC.

Procedure


1. Uncouple the semi-trailer and lift the wheels of the steered axle(s) so that they no longer are in contact with the ground.
2. Turn the ring plate from left to right when lubricating the slewing ring to distribute the grease uniformly over the slewing ring.
3. Remove the surplus grease that comes out from under the seal of the slewing ring.

Lubrication points



600949_01

Figure 10-2




617062_01

Figure 10-3

Notes

Excellent manoeuvrability



JOIST



ROCKINGER

TRIDEC

Edbro



Member of **JOIST**-World

Ekkersrijt 6030
5692 GA Son
The Netherlands
Phone +31 499 49 10 50
www.tridec.com